

## How to ROOT!!!!!!!!!!!!

Prerequisites: ADB, Brain, ZTE ZMAX PRO, USB cable, ADB debugging enabled on phone

- 1) Make sure you have ROOT.zip and QPST.zip. They should be in the same directory as this pdf.
- 2) Start by extracting both files to their own folders
- 3) Connect your phone to a USB 2.0 port on the back of your pc
- 4) Open a command prompt and type in without quotes: "adb devices"
- 5) On your phone, a message should pop up saying if you trust this pc. Click yes.
- 6) Now in command prompt type in: "adb reboot edl"
- 7) Now go to the Downloaded files and extract both zip files
- 8) Go to the QPST folder and go to QPST\bin
- 9) Right click on QFIL.exe and click Run as Administrator
- 10) Select "Flat Build" in qfil
- 11) Click the "Browse" button and go to the other folder named "ROOT"
- 12) Click the drag drop menu with the text "Firehose Programmer" and change it to "All Files"
- 13) Select BCM6153\_V1660\_PreBoot\_20\_KN.bin
- 14) Now it should take you back to the main interface of qfil
- 15) Now click on "Load XML" button and select both rawprogram0.xml and patch0.xml in the "ROOT" folder
- 16) Make sure the top has the text "Qualcomm HS-USB QDLoader 9008"
- 17) Then click Download and wait a couple of seconds until it finishes
- 18) Now disconnect your phone and hold power + vol up and wait until TWRP boots
- 19) DONE! You now have twrp and can now flash magisk for root! Be aware that supersu is not well supported on the phone and should not be used

